

Product Data Sheet

SORB[®]XT Safety-Kit QC

Article	SORB [®] XT Safety-Kit QC
Article No.	100502EN
Dimensions (mm)	400x300x70
Weight	0,70 l
Absorption capacity	2,60 l



Product Information:

Recommended use

- 2L sachet: mobile first aid for smaller leakages
- Barrier Pillow: on usual grounds and on water as a barrier and absorbent
- Quick-Container: set-up container under the area of expected leakage or spill

Application

- spread out SORB[®]XT evenly over the leaked substance and work into the material
- place the pillow directly on the area of contamination and wait until it has reached its full absorptive capacity (the pillow will be entirely in the color of contaminated material)
- the pillow can be applied on all mentioned fields plus on water surfaces

Storage

- store in an dry place with low humidity to avoid mold

After application

- skim off or sweep up the substance from the surface
- collect the substance with pick-up spatula and put it into a disposal bag/ collect the pillow with single-use gloves and put it into a disposal bag
- dispose of the contaminated material following the respective valid laws and local regulations
- clean the quick-container and fold it back to initial shape (reusable)

Properties

- "QC" version includes a mobile, foldable container for "planned" leakages up to 3L
- the Quick Container is set up within seconds and has a resistant foil against oils and fuels
- "QC" Kit contains the following:
 - 1x 2L Sachet of 100% organic SORB[®]XT fibre
 - 1x barrier pillow (filled with 100% organic SORB[®]XT fibre)
 - 1x quick container
 - 1x single-use gloves
 - 2x disposal bag