

Product Data Sheet SORB[®]XT Safety-Kit

| | |
|---------------------|---------------------------------|
| Article | SORB [®] XT Safety-Kit |
| Article No. | 100500EN |
| Dimensions (mm) | 400x300x50 |
| Weight | 0,70 kg |
| Absorption capacity | 2,60 l |



Product Information:

Recommended use

- 2L sachet: mobile first aid for smaller leakages
- barrier pillow: on usual grounds and on water as a barrier and absorbent

Application

- spread out SORB[®]XT evenly over the leaked substance and work into the material
- place the pillows directly on the area of contamination and wait until it has reached its full absorptive capacity (the pillow will be entirely in the color of contaminated material)
- the pillow can be applied on all mentioned fields plus on water surfaces

Storage

- store in an dry place with low humidity to avoid mold

After application

- skim off or sweep up the substance from the surface
- collect the substance with pick-up spatula and put it into a disposal bag/ collect the pillow with single-use gloves and put it into a disposal bag
- dispose of the contaminated material following the respective valid laws and local regulations

Properties

- ideal combination for small leakages, contains the following:
- 1x 2L sachet of 100% organic SORB[®]XT fibre
- 1x barrier pillow (filled with 100% organic SORB[®]XT fibre)
- 1x single-use gloves
- 2x disposal bag